



Velocity Web Services Client 3.6.8.558 Installation Guide & Release Notes

Copyright© 2014-2018, Identiv. Last updated August 1, 2018.

Overview

This document provides information about version 3.6.8.558 of the Velocity Web Services Client, which is an optional browser-based client for Velocity 3.7. The functionality of this version of the Velocity Web Services Client is equivalent to that in version 3.6.7.527 (which corresponds to Velocity 3.6 SP3). Its version number increased because it was rebuilt as part of Velocity 3.7.

A major advantage of the Velocity Web Services Client (compared to the previous Velocity Web Console) is that it uses the same Velocity database. Note that this is a limited-functionality client; only the traditional Windows-based Velocity Client provides access to all of Velocity's extensive functionality. See the [Quick Tour](#) section of this document for a brief summary of the functionality provided by the Velocity Web Services Client.

Before you can install and use the Velocity Web Services Client, you must first install Microsoft's Internet Information Services (IIS) on the same computer where the Velocity Server is installed. If your organization isn't comfortable providing remote access to your physical access control system, do not install IIS or the Velocity Web Services Client.

In this document, there is information about:

- [System Requirements](#)
- [Installing](#) the Velocity Web Services Client (and its prerequisites)
- a [Quick Tour](#) of the Velocity Web Services Client
- the [Known Issues](#) in this release

System Requirements

This version of the Velocity Web Services Client requires the following components:

- A physical access control system with various hardware components controlled by version 3.7 of the Hirsch Velocity security management system software
- The optional Velocity Web Services Client component for your Velocity Server, which can be installed either as part of a full Velocity 3.7 installation, or installed separately later
- A Web server running Microsoft's Internet Information Services (IIS) (version 6.0 or later), which is installed on the same computer where the Velocity Server is installed
- A personal computer, tablet computer, or smartphone running a relatively current Web browser such as Google's Chrome (version 39.0 or later), Microsoft's Internet Explorer (version 11 or later), or Apple's Safari (version 6.2 or later). We recommend using Google's Chrome browser.
- Your device's display should have a resolution of 1024 x 768. (At a lower resolution, you will not be able to see part of a large dialog such as Credential Properties.)
- To use the multiple access zones feature introduced in Velocity 3.6, CCM firmware version 7.5.28 (or later) must be installed on each controller where you want to enable multiple access zones. For details, see VELWC-242 in the **Velocity Web Services Client 3.6.2.10 Installation Guide and Release Notes**.

Installing the Velocity Web Services Client (and its prerequisites)

The optional Velocity Web Services Client can be installed either as part of a full Velocity 3.7 installation, or separately after the Velocity installation. After installing this client, you must also perform a few configuration and setup tasks.



Prerequisites: To install the Velocity Web Services Client, you must be logged into Windows using an account that has Administrator privileges, and you must know the name and password of the Velocity services account (which were specified when Velocity was installed).

NOTES: The Velocity Web Services Client only needs to be installed on your Velocity Server. If you want to install and use this optional client, you must first install Microsoft's Internet Information Services (IIS) on the same computer where the Velocity Server is installed. The installer program checks your existing system to see whether all of the prerequisites for this new client have been met.

Installing Microsoft's Internet Information Services (IIS) to Support the Velocity Web Services Client

Before you can install and use the Velocity Web Services Client, you must first install Microsoft's Internet Information Services (IIS) on either your standalone Velocity workstation or your Velocity server. The following table shows which versions of Windows are supported by Velocity 3.7 for those computer roles.

Computer role:	Versions of Windows supported by Velocity 3.7:
Velocity Server	<ul style="list-style-type: none"> • Windows Server 2008 R2 SP1 • Windows Server 2012 • Windows Server 2012 R2 • Windows Server 2016
Velocity standalone Workstation	<ul style="list-style-type: none"> • Windows Server 2008 R2 SP1 • Windows Server 2012 • Windows Server 2012 R2 • Windows Server 2016 • Windows 7 SP1 • Windows 8.1 • Windows 10


NOTE: This document provides procedures for installing IIS on Windows 7, Windows 10, Windows Server 2008, and Windows Server 2016. Installing IIS on Windows 8.1 should be similar to installing it on Windows 7, and installing IIS on Windows Server 2012 or Windows Server 2012 R2 should be similar to installing it on Windows Server 2008.

To install IIS on Windows 7:

1. From your Windows 7 Start menu, launch **Control Panel**.
2. If you are viewing by Category: click the **Programs** link, and then click the 'Turn Windows Features on or off' link (in the Programs and Features category).

If you are viewing by Small Icons or Large Icons: click **Programs and Features**, and then click the 'Turn Windows Features on or off' link (in the left pane).

3. In the resulting Windows Features dialog, expand the **Internet Information Services** folder to reveal the available options.
4. Check all of the options which are checked in the following screen capture, and then click **OK**.




A progress dialog informs you that Windows is making the requested feature changes. When Windows has finished making the changes, it closes the progress dialog and the Windows Features dialog.

5. Close the Control Panel.

To install IIS on Windows 10:

1. Open **Control Panel**.
2. Locate and click on the **'Turn Windows Features on or off'** link.
3. In the resulting Windows Features dialog, expand the **.NET Framework 3.5 (includes .NET 2.0 and 3.0)**, the **.NET Framework 4.7 Advanced Services**, and the **Internet Information Services** folders to reveal the available options.
4. Check the following set of options, and then click **OK**. (Most of these options are shown in the next screen capture.)
 - **.NET Framework 3.5 (includes .NET 2.0 and 3.0)**
 - **.NET Framework 3.5 (includes .NET 2.0 and 3.0) > Windows Communication Foundation HTTP Activation**
 - **.NET Framework 3.5 (includes .NET 2.0 and 3.0) > Windows Communication Foundation Non-HTTP Activation**
 - **.NET Framework 4.7 Advanced Services > ASP.NET 4.7**
 - **NET Framework 4.7 Advanced Services > WCF Services > TCP Port Sharing**
 - **Internet Explorer 11**
 - **Internet Information Services > Web Management Tools > IIS 6 Management Compatibility**
 - **Internet Information Services > Web Management Tools > IIS 6 Management Compatibility > IIS 6 Management Console**
 - **Internet Information Services > Web Management Tools > IIS 6 Management Compatibility > IIS 6 Scripting Tools**
 - **Internet Information Services > Web Management Tools > IIS 6 Management Compatibility > IIS 6 WMI Compatibility**
 - **Internet Information Services > Web Management Tools > IIS 6 Management Compatibility > IIS 6 Metabase and IIS 6 configuration compatibility**
 - **Internet Information Services > Web Management Tools > IIS Management Console**
 - **Internet Information Services > World Wide Web Services > Application Development Features > .NET Extensibility 3.5**
 - **Internet Information Services > World Wide Web Services > Application Development Features > .NET Extensibility 4.7**
 - **Internet Information Services > World Wide Web Services > Application Development Features > ASP.NET 3.5**
 - **Internet Information Services > World Wide Web Services > Application Development Features > ASP.NET 4.7**
 - **Internet Information Services > World Wide Web Services > Application Development Features > ISAPI Extensions**
 - **Internet Information Services > World Wide Web Services > Application Development Features > ISAPI Filters**
 - **Internet Information Services > World Wide Web Services > Common HTTP Features > Default Document**
 - **Internet Information Services > World Wide Web Services > Common HTTP Features > HTTP Errors**
 - **Internet Information Services > World Wide Web Services > Common HTTP Features > Static Content**
 - **Internet Information Services > World Wide Web Services > Performance Features > Static Content Compression**




A progress dialog informs you that Windows is making the requested feature changes. When Windows has finished making the changes, it closes the progress dialog and the Windows Features dialog.

5. Close the Control Panel.

To install IIS on Windows Server 2008:

1. From your Windows Server 2008 Start menu, launch **Control Panel**.
2. If you are viewing by Category: click the **'Turn Windows Features on or off'** link (at the bottom of the left column).

If you are viewing by Small Icons or Large Icons: click **Programs and Features**, and then click the **'Turn Windows Features on or off'** link (in the left pane).
3. In the resulting Server Manager window, click the **Features** item (in the left pane), and then click the **Add Features** link.
4. In the resulting Add Features Wizard, scroll down and check the **'SMTP Server'** box.
5. In the resulting dialog that asks 'Add role services and features required for SMTP Server?', click the **Add Required Role Services** button.
6. In the Add Features Wizard, click **Next**.
7. On the Web Server (IIS) page of the Add Features Wizard, click **Next**.
8. If necessary, on the Select Role Services page of the Add Features Wizard, expand the **Web Server** folder and the **Management Tools** folder to display the available options.
9. Under Web Server, select these options:
 - the Common HTTP Features option of **Static Content**
 - the Application Development option of **ASP.NET**. (If you receive a dialog that asks 'Add role services required for ASP.NET?', click the Add Required Role Services button.)
 - the Performance option of **Static Content Compression**
10. Scroll down, and under Management Tools, select:
 - **IIS Management Console**
 - **IIS 6 Metabase Compatibility**
 - **IIS 6 WMI Compatibility**
 - **IIS 6 Scripting Tools**
 - **IIS 6 Management Console**
11. Verify that you have selected all of the options which are checked in the following two screen captures, then click **Next**.



12. On the Confirm Installation Selections page of the Add Features Wizard, click **Install**.

On the Installation Progress page of the Add Features Wizard, progress messages are displayed until the installation is complete.

13. On the Installation Results page of the Add Features Wizard, verify that the installation succeeded, and click **Close**.


14. In the Server Manager window, verify that the **Web Server (IIS)** role was installed. You can then close the Server Manager window and the Control Panel.

IIS Options for the Velocity Web Services Client on Windows Server 2012 R2:

The procedure for installing IIS on Windows Server 2012 R2 is very similar to the procedure for installing IIS on Windows Server 2008, with the primary difference being which set of role services must be selected. On Windows Server 2012 R2, verify that you have selected all of the following options:


- Web Server (IIS) > Web Server > Common HTTP Features > **Default Document**
- Web Server (IIS) > Web Server > Common HTTP Features > **Directory Browsing**
- Web Server (IIS) > Web Server > Common HTTP Features > **HTTP Errors**
- Web Server (IIS) > Web Server > Common HTTP Features > **Static Content**
- Web Server (IIS) > Web Server > Performance > **Static Content Compression**
- Web Server (IIS) > Web Server > Application Development > **.NET Extensibility 3.5**
- Web Server (IIS) > Web Server > Application Development > **.NET Extensibility 4.5**
- Web Server (IIS) > Web Server > Application Development > **ASP.NET 3.5**
- Web Server (IIS) > Web Server > Application Development > **ASP.NET 4.5**
- Web Server (IIS) > Web Server > Application Development > **ISAPI Extensions**
- Web Server (IIS) > Web Server > Application Development > **ISAPI Filters**
- Web Server (IIS) > Management Tools > **IIS Management Console**
- Web Server (IIS) > Management Tools > **IIS 6 Management Compatibility**
- Web Server (IIS) > Management Tools > IIS 6 Management Compatibility > **IIS 6 Metabase Compatibility**
- Web Server (IIS) > Management Tools > IIS 6 Management Compatibility > **IIS 6 Management Console**
- Web Server (IIS) > Management Tools > IIS 6 Management Compatibility > **IIS 6 Scripting Tools**
- Web Server (IIS) > Management Tools > IIS 6 Management Compatibility > **IIS 6 WMI Compatibility**

These options are checked in the following two screen captures.




To install IIS on Windows Server 2016:


1. Open **Control Panel**.
2. Locate and click on the **'Turn Windows Features on or off'** link.
3. In the resulting Server Manager window, click the **Features** item (in the left pane), and then click the **Add Features** link.
4. In the resulting **Add Roles and Features Wizard**, provide the necessary information and click **Next** on each of the first few pages.
5. On the **Select server roles** page of the wizard, check the **Web Server (IIS)** role, and click **Next**.



6. In the resulting dialog that asks 'Add features that are required for Web Server (IIS)?', check the option to '**Include management tools (if applicable)**', and click the **Add Features** button.




7. On the **Select features** page of the wizard, check the following options (as shown in the next screen capture), and click **Next**.
- **.NET Framework 3.5 Features**
 - .NET Framework 3.5 Features > **.NET Framework 3.5 (includes .NET 2.0 and 3.0)**
 - .NET Framework 4.6 Features > **ASP.NET 4.6**
 - .NET Framework 4.6 Features > WCF Services > **TCP Port Sharing**



- On the resulting **Web Server Role (IIS)** page of the wizard, read the displayed information, and click **Next**.


9. On the resulting **Select role services** page of the wizard, check the following options (as shown in the next screen capture), and click **Next**.

- **Web Server**
- Web Server > **Common HTTP Features**
- Web Server > Common HTTP Features > **Default Document**
- Web Server > Common HTTP Features > **Directory Browsing**
- Web Server > Common HTTP Features > **HTTP Errors**
- Web Server > Common HTTP Features > **Static Content**
- Web Server > Common HTTP Features > **HTTP Redirection**
- Web Server > **Health and Diagnostics**
- Web Server > Health and Diagnostics > **HTTP Logging**
- Web Server > **Performance**
- Web Server > Performance > **Static Content Compression**
- Web Server > **Security**
- Web Server > Security > **Request Filtering**
- Web Server > **Application Development**
- Web Server > Application Development > **.NET Extensibility 3.5**
- Web Server > Application Development > **.NET Extensibility 4.6**
- Web Server > Application Development > **ASP.NET 3.5**
- Web Server > Application Development > **ASP.NET 4.6**
- Web Server > Application Development > **ISAPI Extensions**
- Web Server > Application Development > **ISAPI Filters**
- **Management Tools**
- Management Tools > **IIS Management Console**
- Management Tools > **IIS 6 Management Compatibility**
- Management Tools > IIS 6 Management Compatibility > **IIS 6 Metabase Compatibility**
- Management Tools > IIS 6 Management Compatibility > **IIS 6 Management Console**
- Management Tools > IIS 6 Management Compatibility > **IIS 6 Scripting Tools**
- Management Tools > IIS 6 Management Compatibility > **IIS 6 WMI Compatibility**
- Management Tools > **IIS Management Scripts and Tools**



10. On the resulting **Confirm installation selections** page of the wizard, check the option to '**Restart the destination server automatically if required**', and review the displayed information to determine whether it is correct.

- If something is **not** correct, click **Previous** to return to the previous page and make the necessary changes.
- If everything is correct, click **Install**.




On the **Installation progress** page of the wizard, progress messages are displayed until the installation is complete.


11. In the Server Manager window, verify that the **Web Server (IIS)** role was installed. You can then close the Server Manager window and the Control Panel.

Installing the Velocity Web Services Client during the Velocity Installation

1. Start following the instructions in the **Installation ► Starting the Velocity Installation** topic of the Velocity 3.6 SP2 Installer's help system.
2. At the **Install Options** screen, select either the **Server** role or the **Workstation** role for your computer.
3. At the resulting **Web Services Options** screen, select the **Install Velocity Web Services** option (to install the Web Services that support the Velocity Web Services Client), then click **Next**.




4. If you selected the **Server** role, then perform the steps in the **Installation ► Server Installation** help topic.
If you selected the **Workstation** role, then perform the steps in the **Installation ► Workstation Installation** help topic.
5. Eventually, the first page of the **Velocity Web Services Client Installer** wizard is displayed. On this **Application Install Option** page, select the appropriate set of options, then click **Next**.



Velocity Web Services Client 3.6.8.558 Installation Guide & Release Notes

- Choose whether to install both the Velocity Web Service and the IIS Client Website, or only the Velocity Web Service.
NOTE: Choosing the option to **Install Velocity Web Service only** enables the last option on this page to **Create Website bundle for separate machine**. This enables you to install the Web site on a different computer than your Velocity Server.
- Choose whether to enable Secure Socket Layer (SSL) communication for the Velocity Web Service.
- If you chose the option to install only the Velocity Web Service on this computer, then you can choose whether to create a Website bundle for installing the Web site on a different computer than your Velocity Server.


After you click the **Next** button, the following screen appears:




The screenshot shows the 'Velocity Web Services Client Installer' window. The title bar is blue with standard Windows window controls. The main window has a light blue header with the title 'Velocity Web Services Client Installer'. Below the header, the main content area is white and titled 'Service and Website Settings'. Under this title, it says 'Provide application service and website settings.' There is a red icon in the top right corner of the content area. The main content area contains a 'Service Configuration' section with a light gray background. Inside this section, it says 'Select existing account to use for authentication'. There are three input fields: 'Service Account:' with the text 'HECQA-780-5\VelocityServices' and a browse button (...), 'Password:' with a masked password of ten dots, and 'Port number:' with a dropdown menu showing '2026'. At the bottom right of the window, there are two buttons: 'Next >' and 'Cancel'.

6. On this **Service and Website Settings** screen:
 - A. In the **Service Account** field, verify or change the user account (by default in the Velocity Services group) that the underlying service for the Velocity Web Services Client will use to log on to Velocity. The default information is automatically obtained for you.
 - B. In the **Password** field, enter the password that the specified Service Account will use to log on to Velocity. (Enter the same password that was used on the **Application Network and Security** page of the Velocity Installer wizard.)
 - C. In the **Port number** field, enter the network port number that will be used for communication between Velocity and the Velocity Web Services Client.
 - D. Click **Next**.


An **Application Installation** screen displays progress information while the Velocity Web Services Client is being installed. For example:




7. If you are updating an existing installation of the Velocity Web Services Client (instead of performing a new installation), then when the following dialog appears, choose whether or not you need the Velocity Web Service use the secured HTTPS protocol when communicating with some other software components.



After the installation of the Velocity Web Services Client has finished, its installer wizard closes, and the primary Velocity installation begins, with progress information displayed on its **Application Installation** page. For example:



8. When the **Installation Complete** screen is displayed, select the desired Closing Options, and click the **Close** button.




After Velocity and the Velocity Web Services Client have finished installing, ensure that:

- [the Velocity Web Service is running](#)
- if you want to use a network port other than the default of 80, you must [configure the network port used by the default IIS Web site](#) to communicate with the Velocity Web Services Client
- [the network port used by the default IIS Web site is allowed through your firewalls](#)

Installing the Velocity Web Services Client Separately (after the Velocity Installation)


To install the Velocity Web Services Client later, perform the following steps.

1. Run the **vwc2install.exe** file located in your Velocity installation folder.
2. The first page of the **Velocity Web Services Client Installer** wizard is displayed. On this **Application Install Option** page, select the appropriate set of options, then click **Next**.




- Choose whether to install both the Velocity Web Service and the IIS Client Website, or only the Velocity Web Service.
NOTE: Choosing the option to **Install Velocity Web Service only** enables the last option on this page to **Create Website bundle for separate machine**. This enables you to install the Web site on a different computer than your Velocity Server.
- Choose whether to enable Secure Socket Layer (SSL) communication for the Velocity Web Service.
- If you chose the option to install only the Velocity Web Service on this computer, then you can choose whether to create a Website bundle for installing the Web site on a different computer than your Velocity Server.

After you click the **Next** button, the following screen appears:




3. On this **Service and Website Settings** screen:
 - A. In the **Service Account** field, verify or change the user account (by default in the Velocity Services group) that the underlying service for the Velocity Web Services Client will use to log on to Velocity.
 - B. In the **Password** field, enter the password that the specified Service Account will use to log on to Velocity. . (Enter the same password that was used on the **Application Network and Security** page when Velocity was installed.)
 - C. In the **Port number** field, enter the network port number that will be used for communication between Velocity and the Velocity Web Services Client.
 - D. Click **Next**.

An **Application Installation** screen displays progress information while the Velocity Web Services Client is being installed. For example:



4. If you are updating an existing installation of the Velocity Web Services Client (instead of performing a new installation), then when the following dialog appears, choose whether or not you need the Velocity Web Service use the secured HTTPS protocol when communicating with some other software components.



After the Velocity Web Services Client has finished installing, ensure that:

- [the Velocity Web Service is running](#)
- if you want to use a network port other than the default of 80, you must [configure the network port used by the default IIS Web site](#) to communicate with the Velocity Web Services Client
- [the network port used by the default IIS Web site is allowed through your firewalls](#)


Ensuring that the Velocity Web Service is Running



Role Permissions: To check the status of the Velocity Web Service, you must have the following Role Permission: **Application Permissions ► Service Control Manager ► Service Control Manager - Use.**

After you install the Velocity Web Services Client, you should use Velocity's Service Control Manager to verify that the Velocity Web Service is running.

Right-click on the Velocity Service Control Manager icon in the Windows taskbar, and look at the commands on the pop-up menu:



- If you see a command to **Start Velocity Web Service**, click on it.
- If you see a command to **Stop Velocity Web Service**, the service is already running, and you should click outside the pop-up menu to close it.

Configuring the network port used by the default IIS Web site


The Velocity Web Services Client works like a typical Web page, and connects to Microsoft's IIS using the HTTP protocol. The default network port is 80, which might already be used by some other program.

If you want to use a network port other than the default of 80, you can perform the following steps to configure the network port used by the default IIS Web site to communicate with the Velocity Web Services Client.

1. From your Windows Server Start menu (on the computer where IIS and the Velocity Server are installed), select **Administrative Tools ► Internet Information Services (IIS) Manager**.
2. In the Connections pane of the **Internet Information Services (IIS) Manager** window, expand the computer name, expand **Sites**, and then click on **Default Web Site**.
3. In the Actions pane (under Edit Site), click on **Bindings**.
4. In the resulting Site Bindings dialog, click the **http** entry, and then click on **Edit**.
5. In the resulting Edit Site Bindings dialog, enter the desired value (such as 8080) for the **Port**, and click **OK**.
6. Close the Site Bindings dialog.
7. In the Actions pane of the **Internet Information Services (IIS) Manager** window (under Manage Web Site), click **Stop**, and then click **Start**.


Ensuring that the Network Port used by the Default IIS Web Site is Allowed Through Your Firewalls

Because the Velocity Web Services Client communicates across a shared network (instead of a dedicated physical security network), you will have to work with your network administrator to ensure that the network port used by the default IIS Web site is allowed through your firewalls. Some networks use the software firewall provided with Microsoft Windows, other networks use a software firewall provided by a different vendor (as shown in the following image), and high-security networks include hardware firewalls.




Because the firewalls on a network can vary so much, we cannot provide a detailed procedure for your specific network. But the following example for the Windows 7 Firewall should help illustrate the general process.

1. Open the Windows 7 **Control Panel**, and click on the **Windows Firewall** link.




2. Click on the **Advanced settings** link (in the left column).

3. In the resulting **Windows Firewall with Advanced Security** window, click on **Inbound Rules** (in the left pane), and then click on **New Rule...** in the Actions pane.



4. On the **Rule Type** page of the resulting **New Inbound Rule Wizard**, select the **Port** option, and then click **Next**.




5. On the **Protocol and Ports** page, select the **TCP** option, select the **Specific local ports** option and enter the desired value (such as 8080), and then click **Next**.

The screenshot shows the 'New Inbound Rule Wizard' window, specifically the 'Protocol and Ports' step. The title bar reads 'New Inbound Rule Wizard'. The main heading is 'Protocol and Ports' with the instruction 'Specify the protocols and ports to which this rule applies.' On the left, a 'Steps:' pane lists 'Rule Type', 'Protocol and Ports' (highlighted), 'Action', 'Profile', and 'Name'. The main area contains two questions: 'Does this rule apply to TCP or UDP?' with radio buttons for 'TCP' (selected) and 'UDP'; and 'Does this rule apply to all local ports or specific local ports?' with radio buttons for 'All local ports' and 'Specific local ports' (selected). Below the second question is a text input field containing '8080' and an example text 'Example: 80, 443, 5000-5010'. At the bottom, there are three buttons: '< Back', 'Next >' (with a mouse cursor over it), and 'Cancel'. A link 'Learn more about protocol and ports' is also present.


6. On the **Action** page, click **Next** to accept the defaults.

The screenshot shows the 'New Inbound Rule Wizard' window, specifically the 'Action' step. The title bar reads 'New Inbound Rule Wizard'. The main heading is 'Action' with the instruction 'Specify the action to be taken when a connection matches the conditions specified in the rule.' On the left, a 'Steps:' pane lists 'Rule Type', 'Protocol and Ports', 'Action' (highlighted), 'Profile', and 'Name'. The main area contains the question 'What action should be taken when a connection matches the specified conditions?' with three radio button options: 'Allow the connection' (selected), 'Allow the connection if it is secure', and 'Block the connection'. The 'Allow the connection' option has a description: 'This includes connections that are protected with IPsec as well as those are not.' The 'Allow the connection if it is secure' option has a description: 'This includes only connections that have been authenticated by using IPsec. Connections will be secured using the settings in IPsec properties and rules in the Connection Security Rule node.' Below this is a 'Customize...' button. At the bottom, there are three buttons: '< Back', 'Next >' (with a mouse cursor over it), and 'Cancel'. A link 'Learn more about actions' is also present.

- On the **Profile** page, click **Next** to accept the defaults.



- On the **Name** page, enter the required **Name**, optionally enter a **Description**, and click **Finish**.




Quick Tour of the Velocity Web Services Client


This section provides a high-level quick tour of the functionality available in the Velocity Web Services Client.

Logging In to the Velocity Web Services Client

The Login page is used to log in to this client. Enter the username and password of an existing Velocity operator, and click the **Login** button. If either the username or the password is incorrect, the following error message is displayed:




Commands on the Operator drop-down menu




After you successfully log in to the Velocity Web Services Client, there is an Operator drop-down menu (in the upper right corner) that includes commands to:

- display an **About** dialog which shows version information for Velocity and the Velocity Web Services Client




Velocity Web Services Client 3.6.8.558 Installation Guide & Release Notes


- open the **Settings** page where you can specify some options for the Velocity Web Services Client (including the “Landing Page” which is the default page displayed after you log in)



The screenshot shows the 'Velocity - Settings' web application. The browser address bar displays '10.1.1.20/VWSC/Configuration/ConfigurationManager'. The page features the 'IDENTIV' logo and a navigation bar with tabs: 'Enrollment', 'Alarms', 'Device Control', 'Reporting', and 'Status Dashboard'. The 'Settings' section is active, with sub-tabs for 'General', 'Alarms', and 'Events'. The 'General' tab is selected, showing 'Landing Page' set to 'Enrollment' and 'Region' set to 'English - United States'. An 'Apply Changes' button is located at the bottom right.




The screenshot shows the 'Velocity - Settings' web application with the 'Alarms' tab selected. The 'Maximum Page Size' is set to 'Show 50 alarms per page (Max : 100)'. The 'Alarm Sorting' section has a checkbox for 'Display Alarms Most Recent to Oldest'. The 'Alarm Acknowledge Options' section includes several checkboxes: 'Require Acknowledge before Clearing' (checked), 'Require Entry of Note on Acknowledge', 'Force New Note for Multiple Acknowledge', 'Require Entry of Note on Clear', and 'Force New Note for Multiple Clear'.



The screenshot shows the 'Velocity - Settings' web application with the 'Events' tab selected. The 'Maximum Page Size' is set to 'Show 50 events per page (Max : 100)'. The 'Show Events' section includes several checkboxes: 'On Enrollment Page' (checked), 'On Device Control Page' (checked), 'On Alarms Page' (checked), and 'Load Cached Events' (checked).


Velocity Web Services Client 3.6.8.558 Installation Guide & Release Notes

- logout from your current session (and return to the Login page)



Enrollment page

The **Enrollment** page of the Velocity Web Services Client provides the most important functionality of Velocity's Enrollment Manager.



Velocity Web Services Client 3.6.8.558 Installation Guide & Release Notes

By default, this page also includes an Events pane which provides the most important functionality of Velocity's Event Viewer. (You can remove the Events pane by unchecking the **Show Events On Enrollment Page** option on the Events tab of the Settings page.)

Alarms page

The **Alarms** page of the Velocity Web Services Client provides the most important functionality of Velocity's Alarm Viewer (including any pre-defined Instructions to the operator for a specific type of alarm and Notes entered by the operator to document their response to a specific alarm).

The screenshot displays the Velocity Web Services Client interface. The top navigation bar includes tabs for Enrollment, Alarms, Device Control, Reporting, and Status Dashboard. The Alarms tab is active, showing a section for Alarms with the message "There are no active alarms at this time". Below this is a table of Acknowledged Alarms. The Events section at the bottom shows a list of events with columns for Host Time, Controller Time, Description, Address, Event Type, and Event ID. The sidebar on the right contains a section for Instructions and Notes, with a note dated 12/23/2014 03:00:40 PM by Administrator stating "Verified that my card worked at the main lobby door."

Action	Host Time	Controller Time	Acknowledge Time	Description	Address	Acknowledged By
+	12/19/2014 08:50:30 AM		12/19/2014 08:50:30 AM	uTrustVerge Service online	\\Verge.001	Velocity

Host Time	Controller Time	Description	Address	Event Type	Event ID
12/23/2014 02:53:42 PM		Operator ADMINISTRATOR logged on to web client 10.1.1.5	\\HECQA-GX620-20.001	Software	1316
12/23/2014 02:43:55 PM	12/23/2014 02:43:47 PM	Relay Relay 02 state change (0) none	\\XNET.001.0002.001.01.BR02	DIGITRAC Internal	9033
12/23/2014 02:43:49 PM	12/23/2014 02:43:41 PM	Access granted: Ron LasMarias Door 02-Reader 02	\\XNET.001.0002.001.01.SM02	DIGITRAC Transaction	2000
12/23/2014 02:43:49 PM	12/23/2014 02:43:41 PM	Relay Relay 02 state change (1) door trigger	\\XNET.001.0002.001.01.BR02	DIGITRAC Internal	9033
12/23/2014 02:20:02 PM		Operator Administrator logged on to workstation HECQA-GX620-20	\\HECQA-GX620-20.001	Software	1022
12/23/2014 02:05:58 PM		Operator ADMINISTRATOR disconnected from workstation HECQA-GX620-20	\\HECQA-GX620-20.001	Software	1031
12/23/2014 12:00:06 PM	12/23/2014 12:00:00 PM	Warning! System code is 123 at controller (Mx4) Controller IP #246 - MSTR	\\XNET.001.0002.001.01	Miscellaneous	8015
12/23/2014 12:00:05 PM	12/23/2014 12:00:00 PM	Warning! System code is 123 at controller (M8) Controller IP #192	\\XNET.001.0001.001.01	Miscellaneous	8015
12/23/2014 12:00:05 PM	12/23/2014 12:00:00 PM	Warning! System code is 123 at controller (M2) Controller RS485 - SLV	\\XNET.001.0002.001.02	Miscellaneous	8015

DIGITRAC Service: Online Active Alarms: 0 Ack Alarms: 0 Off Normal: 0 Threat Level: Level 00

By default, this page also includes an Events pane which provides the most important functionality of Velocity's Event Viewer. (You can remove the Events page by unchecking the **Show Events On Enrollment Page** option on the Events tab of the Settings page.)

Device Control page

The **Device Control** page of the Velocity Web Services Client provides the most important functionality of Velocity's Administration window.

The screenshot displays the Velocity Web Services Client interface. The top navigation bar includes tabs for Enrollment, Alarms, Device Control (selected), Reporting, and Status Dashboard. The user is logged in as Administrator.

Device Control Table:

Action	Name	Index	Address
Access ▾ Control ▾	Door 01	1	\\XNET.001.0001.001.01.DR01
Access ▾ Control ▾	Door 01	1	\\XNET.001.0002.001.01.DR01
Access ▾ Control ▾	Door 01	1	\\XNET.001.0002.001.02.DR01
Access ▾ Control ▾	Door 02	2	\\XNET.001.0002.001.02.DR02
Access ▾ Control ▾	Door 02	2	\\XNET.001.0002.001.01.DR02
Access ▾ Control ▾	Door 02	2	\\XNET.001.0001.001.01.DR02
Access ▾ Control ▾	Door 03	3	\\XNET.001.0001.001.01.DR03
Access ▾ Control ▾	Door 03	3	\\XNET.001.0002.001.01.DR03
Access ▾ Control ▾	Door 03	3	\\XNET.001.0002.001.02.DR03
Access ▾ Control ▾	Door 04	4	\\XNET.001.0002.001.02.DR04
Access ▾ Control ▾	Door 04	4	\\XNET.001.0002.001.01.DR04
Access ▾ Control ▾	Door 04	4	\\XNET.001.0001.001.01.DR04
Access ▾ Control ▾	Door 05	5	\\XNET.001.0001.001.01.DR05
Access ▾ Control ▾	Door 06	6	\\XNET.001.0001.001.01.DR06

Events Table:


Host Time	Controller Time	Description	Address	Event Type	Event ID
12/22/2014 02:02:48 PM		Operator ADMINISTRATOR logged on to web client 10.1.1.5	\\HECQA-GX620-20.001	Software	1316
12/22/2014 01:42:07 PM		Operator ADMINISTRATOR logged off from web client 10.1.1.5	\\HECQA-GX620-20.001	Software	1317
12/22/2014 01:40:44 PM		Operator ADMINISTRATOR logged on to web client 10.1.1.5	\\HECQA-GX620-20.001	Software	1316

At the bottom of the interface, there is a status bar showing: DIGITRAC Service: Online, Active Alarms: 0, Ack Alarms: 0, Off Normal: 0, and Threat Level: Level 00.


By default, this page also includes an Events pane which provides the most important functionality of Velocity's Event Viewer. (You can remove the Events page by unchecking the **Show Events On Enrollment Page** option on the Events tab of the Settings page.)

Reporting page

The **Reporting** page of the Velocity Web Services Client provides the most important functionality of Velocity's Report Manager.




After you click **Generate Report**, a progress indicator is displayed until the request has completed. If the report fails for some reason, an error message is displayed. If the report succeeds, a Report Generated dialog with an **Open Report** button is displayed. When you click that button, the resulting .PDF file is opened in a new tab of the current browser window.



Status Dashboard page


The **Status Dashboard** page of the Velocity Web Services Client displays information about:

- the summary status of your People and Credentials
- the access that was granted or denied today
- the Live Events
- the Queued Downloads to your controllers



Status Bar


The status bar at the bottom of the Velocity Web Services Client shows some status information about your Velocity system, including alarms and the threat level.



The items shown in blue are hyperlinks. If you click on the **Active Alarms** link or the **Ack Alarms** link, the Alarms page is displayed. If you click on the **Off Normal** link, the Off Normal Points dialog is displayed.

Pull-Out Menus for Narrow Browser Windows

When your Web browser window is too narrow to display all the information on certain pages of the Velocity Web Services Client, the smaller pane is moved to a pull-out menu on either the left or the right side. For example, on the Alarms page, the Instructions and Notes can move to a pull-out menu on the right side. On the Enrollment page, the Person Groups and the Persons list can move to a pull-out menu on the left side:



New Features and Enhancements

There are no new features in this release (relative to the 3.6.7.527 release).

Bug Fixes

There are no bug fixes in this release (relative to the 3.6.7.527 release).

Known Issues

Reference ID	Summary	Description
VELWC-79	Status of an IDF 0 (Badge Only) credential is different in the VWSC versus the traditional Velocity Client	When a credential is set to IDF 0 (Badge Only), there are some differences in the status displayed in the Velocity Web Services Client versus the traditional Windows-based Velocity Client. There is no workaround for this issue.
VELWC-139	Report generated in the VWSC by a non-Admin operator has a "Printed by:" value of VELOCITYSERVICES	When a non-Admin operator generates a report in the Velocity Web Services Client, the "Printed by:" value is VELOCITYSERVICES. The workaround is to generate the report in the traditional Windows-based Velocity Client, which does display the correct operator name.
VELWC-204	Version 11 of Internet Explorer (or a different browser) is required to create a person or a credential	If you try to use version 8 (or earlier) of Microsoft's Internet Explorer with the Velocity Web Services Client, you cannot create a person or a credential. To use Internet Explorer, you must upgrade it to version 11 (or later). Alternatively, you can use a different browser such as Google's Chrome (version 39.0 or later).
VELWC-231	The Date/Time format is not consistent across the VWSC	In the Velocity Web Services Client, a Date/Time is not displayed in a consistent format. It is displayed differently in: <ul style="list-style-type: none"> the activation and expiration fields of a credential the date/time fields of a report's selection Criteria There is no workaround for this issue.
VELWC-236	Expire on UDF date option is not disabled if there are no UDFs with the type of Date.	When you set the expiration date for a credential using the Velocity Web Services Client, the Expire on UDF date option (on the Set Expiration Date dialog) is not disabled if there are no User-Defined Fields with the type of Date. There is no workaround for this issue.
VELWC-295	When using an unsupported browser, you cannot create a new user	When using an older browser which is not supported by the VWSC (such as Microsoft's Internet Explorer version 8), you cannot create a new user on the Enrollment page. The workaround is to use a supported browser, such as Google's Chrome (version 39.0 or later), Microsoft's Internet Explorer (version 11 or later), or Apple's Safari (version 6.2 or later).